## Interfill 830 Fast Cure

## **Fillers**

**Epoxy Profiling Filler** 



#### PRODUCT DESCRIPTION

Interfill 830 Fast Cure is the best choice for profiling above and below the waterline on Steel, Aluminium and Composite hulls. The special 2-component light grey epoxy formulation can fill up to a thickness of 2cm (20,000 microns) in one coat without the risk of sagging/slumping @ 23°C.

- \* Fast curing at lower temperatures
- \* Low density composition
- \* High strength and impact resistance
- \* Easy sanding
- \* Waterproof

San Pot

When sanded, the surface of the Interfill 830 Fast Cure is smooth enough to be directly overcoated with Interprime 820 high build epoxy primer or Interprime 880. Interfill 830 Fast Cure is particularly suitable for application over large areas at low temperatures and also for filling smaller areas when rapid sanding or overcoating is required.

### PRODUCT INFORMATION

Colour **YAA867** Finish Matt **Specific Gravity** 0.74 **Volume Solids** 100%

Mix Ratio 1:1 by volume (as supplied) . Mix ratio by weight: 1.17:1 YAA867:YAA869

Converter/Curing Agent **YAA869 Typical Shelf Life** 2 yrs VOC (As Supplied) 84 g/lt **Unit Size** 5 Lt 20 Lt

#### DR

RYING/OVERCOATING INFORMATION										
	Drying									
	10°C (50°F)	15°C (59°F)	23°C (73°F)	35°C (95°F)						
_										
ındable	16 hrs	16 hrs	6 hrs	3 hrs						
ot Life	50 mins	45 mins	35 mins	20 mins						

#### Overcoating **Substrate Temperature**

Overcoated By	10°C (50°F)		15°C (59°F)		23°C (73°F)		35°C (95°F)	
	Min	Max	Min	Max	Min	Max	Min	Max
Interfill 830 Fast Cure	24 hrs	ext	24 hrs	ext	6 hrs	ext	6 hrs	ext
Interfill 833	24 hrs	ext	24 hrs	ext	6 hrs	ext	6 hrs	ext
Interfill 833 Fast Cure	24 hrs	ext	24 hrs	ext	6 hrs	ext	6 hrs	ext
Interfill 835	24 hrs	ext	24 hrs	ext	6 hrs	ext	6 hrs	ext
Interprime 820	24 hrs	ext	24 hrs	ext	6 hrs	ext	6 hrs	ext
Interprime 880	24 hrs	ext	24 hrs	ext	6 hrs	ext	6 hrs	ext
Interprotect	24 hrs	ext	24 hrs	ext	6 hrs	ext	6 hrs	ext
Interprotect (Professional)	24 hrs	ext	24 hrs	ext	6 hrs	ext	6 hrs	ext

Note: Once the sandable time has been exceeded, all fillers should be sanded before overcoating to promote good adhesion. A sanded filler may be left for a period up to 3 months before being overcoated with further epoxy filler or with Interprime 8-series. After 3 months the filler must then be re-sanded before overcoating.

#### **APPLICATION AND USE**

Preparation All substrates must be clean, dry and free from contaminants.

PREVIOUSLY PAINTED SURFACES

In Good Condition Wash down with Super Cleaner, rinse with fresh water and allow to dry. Abrade with 80-180 grade paper

In Poor Condition/Repairs: All previous coatings should be removed back to solid material and primed.

STEEL/ALUMINIUM Prime with Intergard 269 or Interprime 820.

BARE WOOD For stable constructions only; prime with Interprime 820.

GRP Degrease with solvent, Super Cleaner or a suitable liquid detergent Degrease with solvent, Super Cleaner or a suitable liquid detergent. Sand well using 180-220 grade paper. Clean thoroughly and allow to dry. Pre-prime using an International primer as detailed for specific coating systems.

Please refer to your local representative or visit www.international-yachtpaint.com for further information

All trademarks mentioned in this publication are owned by, or licensed to, the AkzoNobel group of companies. © AkzoNobel 2024

# Interfill 830 Fast Cure

### **Fillers**

**Epoxy Profiling Filler** 

**X.International.** 

BARE GRP/COMPOSITESand with 80-180 grade (grit) paper.If left for longer than 24 hours, two component epoxy

primers and fillers will need sanding with 80-180 grade paper to ensure a good physical key.

Method Remove any dust from the surface. Apply firmly in a spreading action. When hardened, sand smooth with 80-180 grade

wet or dry paper. Spread mix out on a board to avoid excess heat build up and to keep the working life as long as possible. When fairing a hull, two or three 'cross coats' of Interfill 830 will ensure the desired shape is obtained. Where

large areas have been faired, sand with a longboard to allow for the curvature of the hull.

Hints Mixing Mix both components together thoroughly to correct mix ratio. Mix the two components thoroughly to an even

colour.

Thinner Do not wipe down cured filler with solvent.

Thinning Do not thin.

Cleaner GTA220 for equipment cleaning only.

Some Important Points Do not apply more than 2.0 cm thickness at any one time. Do not use below 10°C/50°F. Standard and fast cure systems

MUST NOT be wet mixed in order to obtain intermediate cure times or to use up spare filler. The systems are fully compatible in the cured state. Product temperature should be minimum 10°C/50°F and maximum 35°C/95°F. Ambient temperature should be minimum 10°C/50°F and maximum 35°C/95°F. Substrate temperature should be minimum 10°C/50°F

and maximum 35°C/95°F.

Compatibility/Substrates

Do not use on traditional wood constructions where the wood will expand and contract through changes in the moisture

content. Interfill 830 Fast Cure should be applied over cured epoxy primers or fillers or onto cured GRP/Composite. Interfill 830 Fast Cure may be overcoated with Interfill 833, Interprime 820, Interprime 850, Interprime 880 or Interfill 835 (YAA855/YAA856). Gelshield or Gelshield 200 may be used over Interfill 830 within the osmosis schemes.

Number of Coats As required

Coverage (Theoretical) - 0.2 m<sup>2</sup>/L per coat @ 5000 micron (200 mil) WFT.

**Recommended DFT per coat** 20000 microns dry By Trowel or Batten. **Recommended WFT per coat** 20000 microns wet By Trowel or Batten.

Application Methods Batten, Trowel

#### TRANSPORTATION, STORAGE AND SAFETY INFORMATION

Storage GENERAL INFORMATION:

Exposure to air and extremes of temperature should be avoided. For the full shelf life of Interfill 830 Fast Cure to be realised ensure that between use the container is firmly closed and the temperature is between 5°C/41°F and 35°C/95°F.

Keep out of direct sunlight. **TRANSPORTATION:** 

Interfill 830 Fast Cure should be kept in securely closed containers during transport and storage.

Safety GENERAL: Read the label safety section for Health and Safety Information, also available from our Technical Help Line.

DISPOSAL: Do not discard tins or pour paint into water courses, use the facilities provided. It is best to allow paints to

harden before disposal.

Remainders of Interfill 830 Fast Cure cannot be disposed of through the municipal waste route or dumped without permit.

Disposal of remainders must be arranged for in consultation with the authorities.

IMPORTANT NOTES

The information given in this sheet is not intended to be exhaustive. Any person using the product without first making further written enquiries as to the suitability of the product for the intended purpose does so at their own risk and we

further written enquiries as to the suitability of the product for the intended purpose does so at their own risk and we can accept no responsibility for the performance of the product or for any loss or damage (other than death or personal

injury resulting from negligence) arising out of such use. The information contained in this sheet is liable to modification from time to time in the light of experience and our policy of continuous product development.